

---

---

MAINTENANCE INSTRUCTIONS

---

---

## SHOWER CLEANING INSTRUCTIONS NATURAL STONE Including RIVERSTONE TILE & GROUT FLOORS

Alkaline & neutral cleaners are what are necessary to effectively clean natural stone showers. We recommend buying a quality commercial alkaline concentrated cleaner.

**ACIDIC CLEANERS WILL POTENTIALLY BURN NATURAL STONE SURFACES  
PROPERLY PROTECT ALL MARBLES, TRAVERTINE OR ANY OTHER ACID SENSITIVE SURFACES**

1. Always make sure you have adequate ventilation & fresh water to rinse and neutralize tub surround or shower stall before cleaning outlined in the following lines.
2. Dilute 250 ml. Alkaline concentrate with 2 Litres warm water.
3. Apply diluted cleaner to the walls and floor generously with a sponge, allow to stand for 1 - 2 minutes, this will allow cleaner to emulsify and loosen any dirt and soil on your surfaces.
4. Using rubber or nitrile gloves and safety glasses for protection, scrub all surfaces with wet white scotch pad.  
**Be sure to keep all surfaces wet.**
5. Thoroughly Rinse all surfaces with fresh cold water. Upon completion and as surfaces dry, it may be necessary to repeat steps 2 through 4 to remove heavy calcium and lime deposits.
6. Finally, a quick polish of any chrome fixtures with metal polish will bring back original lustre with any commonly purchased metal polish.

**It may be necessary for occasional professional cleaning where commercial tools will take the cleaning to the next level.**

**We highly recommend using a shower squeegee after every use as this will help to prevent any calcium and lime build up on the tiles.**

For the most up-to-date version of this maintenance instruction, please visit the "Flooring" section of our website at [www.strassburgertile.ca](http://www.strassburgertile.ca).